



When piston is in top position  
the indicator-mark must be  
in shown position.

N		TYPE: HYDRAULICAL		SCALE: 1:1	
Approved for Release (IFR) - This report is classified "CONFIDENTIAL" and its contents should not be distributed outside the limits of the original report or to any other person without the express approval of the appropriate authority.		DATE: 1957 BY: [Signature] CHECKED: [Signature]		DRAWING NO: BRC 052 PART NO: A1 / 051 B 3 9 6 1	
TITLE: DANFORS SYSTEM HYDRAULIKAS ASSEMBLY DRAWING		SCALE: 1:1		PART NO: A1 / 051 B 3 9 6 1	